



Benefits

- Measures the concentration of all types of diet / regular drinks and diet syrups
- High accuracy with all types of beverages
- Quick measurement
- Fully automatic with no sample preparation
- No need of skilled operators

NEXT GENERATION diet soft-drinks lab analyzer

The Maselli DR30 laboratory analyzer is the latest evolution of the iconic DR10 Easy-Diet™. The new design confirms the capability to measure the concentration of diet or sugar-free carbonated soft drinks, flavoured water and energy drinks replacing simultaneously HPLC units, spectrophotometers, titrators and other manual systems and methods.

In comparison with DR10, the new DR30 is dramatically reducing the maintenance by means of new electronics able to handle an updated temperature control system based on a sophisticated Peltier cell controller. The DR30 indicates the concentration in milli-Brix converting it to %STANDARD or Total Acidity according to laboratory existing procedures. Measuring cycle is usually carried out in less than 5 minutes.

The system is completely automated and extremely simple and easy to use; just pour the sample into the beaker and press the start button to start the analysis. No expert operators are required since no specific analysis methodologies or sample preparation (conditioning) procedures are needed. This also has an impact on the total reduction of risks related to chemical hazards since no special reagents are needed for the conduction of the analysis. The presence of a touch-screen display helps the operator interface in the daily operation: all the data may be exported easily to plant network.

DR30

LAB DIFFERENTIAL REFRACTOMETER

DIET SOFT DRINKS CONCENTRATION

IB08 PLUS+ - Beverage Analyzer

The beverage analyzer IB08 is the only system able to measure accurately any kind of beverage in the portfolio of a soft drinks bottling plant including diet, beverages with fibers and flavored waters. The equipment is based on optical technology: refractive index for Bx/Diet measurement and infrared for CO₂ one (P/T based CO₂ analyzer also available upon request).



OPERATING SPECIFICATION

Measurement range:	0...20 RD
Accuracy:	0.5% of measurement, max accuracy 0.00125 RD
Measurement scales:	%STANDARD; Total Acidity; Brix; RD
Analysis Cycle time:	7 minutes for a complete cycle
Quantity of analyzed sample:	Product: ~100 cc for each test Water: ~50 cc for each test

TECHNICAL FEATURES

Product temperature:	5...25°C (41...77°F)
Power supply:	AC 100...240V +/- 10%, 47...63Hz, 150VA
Interfaces:	ETHERNET: RJ45 for external connection USB: type A for external connection PS/2: MiniDIN 6 P.F. for keyboard and mouse connection

Please refer to the technical datasheet for further data.

More products for the analysis of liquids concentration

LP10

Laboratory Soft Drink
Analyzer



Laboratory – Diet, Brix, Fresh
Brix, CO₂

TP10

TPO Analyzer



Laboratory – TPO, CO₂, HS
Volume



maselli
PROCESS ANALYZERS



7411
www.maselli.com

